

## a Classic Display Case – U-Build

Self-Serve and Attendant Serve Available.  
Includes 4 – 13" x 18" Clear Trays.  
Assembly Required.

ITEM	DESCRIPTION
1012	13½Wx21Dx24½H
1012-S	13½Wx21Dx24½H
325-13-12	Replacement Tray



1012

a



1012-S Self-Serve

## b Classic Display Case – U-Build

Self-Serve and Attendant Serve Available.  
Includes 3 – 13" x 18" Clear Trays.  
Assembly Required.

ITEM	DESCRIPTION
1011	19½Wx17Dx16½H
1011-S	19½Wx17Dx16½H
325-13-12	Replacement Tray



1011

b



1011-S Self-Serve

## c Classic Display Case – U-Build

Self-Serve. Includes 3 Clear Trays.  
Assembly Required.

ITEM	DESCRIPTION
942-S	13½Wx22Dx21H - 13x18 Tray
963-S	11½Wx17Dx17H - 10x14 Tray
325-13-12	Replacement Tray - 13x18
335-10-12	Replacement Tray - 10x14



c

942-S 13" x 18" Self-Serve  
963-S 10" x 14" Self-Serve

d



941 13" x 18"  
960 10" x 14"

## d Classic Display Case – U-Build

Attendant Serve.  
Includes 3 Clear Trays.  
Assembly Required.

ITEM	DESCRIPTION
941	13½Wx22Dx21H-13x18 Tray
960	11½Wx17Dx17H-10x14 Tray

### Replacement Trays

325-13-12	Replacement 13x18 Tray
335-10-12	Replacement 10x14 Tray