

Wear-Ever® Bakeware

Wear-Ever® Cookie Sheets



- Heavy-gauge 3004 aluminum heats rapidly and evenly
- Available in natural finish aluminum or coated with SteelCoat x3™ premium non-stick for easy release of delicate baked goods

| ITEM | FINISH | DIMENSIONS IN (CM) | GAUGE | CASE LOT |
|-------|---------------|--------------------------|-------|----------|
| 68085 | Natural | 17 x 14 (43.2 x 35.6) | 10 | 6 |
| 68084 | SteelCoat x3™ | 17 x 14 (43.2 x 35.6) | 10 | 6 |

**Holy Grail of
Cookie Sheets!**

Source: Cook's Illustrated and NBC® Today® Show, aired May 2008

NBC and Today Show are registered trademarks of National Broadcasting Company, Inc.

Wear-Ever® Heavy-Duty Aluminum Roasters



- Extra dent-resistances 3004 aluminum
- Traditional standard with the military
- Easy-to-grab loop handle on all four sides of pan
- Cover can be used as a griddle

| ITEM | PREVIOUS ITEM # | DESCRIPTION | CAPACITY: QT (L) | DIMENSIONS: IN (CM) | GAUGE | CASE LOT |
|-------|-----------------|----------------|------------------|---|-------|----------|
| 68390 | — | Pan with cover | 42 (39.7) | 20 ⁷ / ₈ x 17 ⁷ / ₈ x 9 (53 x 44.1 x 22.9) | 4 | 1 |
| 68391 | 4493 | Pan only | 42 (39.7) | 20 ⁷ / ₈ x 17 ⁷ / ₈ x 7 (53 x 44.1 x 17.8) | 4 | 1 |
| 68392 | 4492 | Cover only | 14 (13.2) | 21 ⁵ / ₈ x 18 ¹ / ₈ x 2 ⁵ / ₈ (54.9 x 46 x 6) | 4 | 1 |



Wear-Ever® Aluminum Roasters



- Heavy-gauge 3004 aluminum with beadless rims
- When used as double roasters, section fits snugly to seal in steam
- Top or bottom sections may be used individually for open pan roasting
- Protective chrome-plated steel straps on 68360, 68361, and 68362
- Loop handles for durability
- Heats evenly and efficiently — recommend reducing oven temperature by 25°F (-3.9°C) to reduce energy costs



| ITEM | PREVIOUS ITEM # | DESCRIPTION | DIMENSIONS IN (CM) | CAPACITY QT (L) | GAUGE | CASE LOT |
|--------|-----------------|---|---|---------------------------------------|-------|----------|
| 68360 | — | Double roaster set top and bottom with straps | 20 ⁷ / ₈ x 16 ¹ / ₈ x 9 ³ / ₄ (51.1 x 41 x 24.8) | 23 ¹ / ₄ (22) | 12 | 1 |
| 4482 | — | Strapped roast pan top for 68360 | 20 ⁷ / ₈ x 16 ¹ / ₈ x 4 ¹ / ₂ (51.1 x 41 x 11.4) | 11 ¹ / ₂ (10.8) | 12 | 2 |
| 448212 | — | Strapped roast pan bottom for 68360 | 20 ⁷ / ₈ x 16 ¹ / ₈ x 4 ¹ / ₂ (51.1 x 41 x 11.4) | 11 ¹ / ₂ (10.8) | 12 | 2 |
| 68361 | 4483 | Roasting pan — top with straps | 24 x 18 x 4 ³ / ₄ (61 x 45.7 x 12.1) | 29 ¹ / ₂ (27.9) | 10 | 2 |
| 68362 | 448312 | Roasting pan — bottom with straps | 24 x 18 x 4 ³ / ₄ (61 x 45.7 x 12.1) | 29 ¹ / ₂ (27.9) | 10 | 2 |
| 68363 | 4432 | Roasting pan top | 19 ¹³ / ₁₆ x 21 ¹³ / ₁₆ x 2 ³ / ₈ (50.3 x 55.4 x 6) | 16 (15.1) | 12 | 6 |
| 68364 | 4433 | Roasting pan top | 19 ¹³ / ₁₆ x 21 ¹³ / ₁₆ x 3 ⁵ / ₈ (50.3 x 55.4 x 9.2) | 23 ¹ / ₂ (22.2) | 12 | 2 |
| 68365 | 4436 | Roasting pan bottom | 22 ¹ / ₈ x 20 ¹ / ₈ x 6 ⁹ / ₁₆ (56.2 x 51.1 x 16.6) | 42 ¹ / ₂ (40.2) | 10 | 2 |
| 68366 | 4423 | Roasting pan top | 19 ³ / ₄ x 10 ⁷ / ₈ x 3 ⁵ / ₈ (50.2 x 27.6 x 9.2) | 11 ¹ / ₄ (10.6) | 14 | 2 |
| 68367 | 4426 | Roasting pan bottom | 20 x 11 ¹ / ₈ x 5 ¹ / ₂ (50.8 x 28.3 x 14) | 17 ³ / ₄ (16.8) | 12 | 2 |