



	<i>weight</i>	<i>length</i>	<i>width</i>	<i>height</i>	<i>cubic feet</i>	<i>UPC</i>	<i>list price ea.</i>
L6C03 6 Inch / 1 Quart Camp Dutch Oven, 3 inch depth							
<i>item</i>	7 LB	6.75 L	8 W	6.13 H	0.19 FT ³	075536-38060-5	
<i>case</i>	7 LB	7.88 L	7.25 W	5.88 H	0.19 FT ³	1-00-75536-38060-2	1 PACK



L8C03 8 Inch / 2 Quart Camp Dutch Oven, 3 inch depth							
<i>item</i>	10 LB	8.25 L	9.5 W	6 H	0.27 FT ³	075536-38080-3	
<i>case</i>	10 LB	9.63 L	9.13 W	6.25 H	0.27 FT ³	1-00-75536-38080-0	1 PACK



L10C03 10 Inch / 4 Quart Camp Dutch Oven, 3.5 inch depth							
<i>item</i>	13 LB	11.75 L	10.5 W	6 H	0.43 FT ³	075536-38100-8	
<i>case</i>	13 LB	11.88 L	11.25 W	6.75 H	0.45 FT ³	1-00-75536-38100-5	1 PACK



L10DC03 10 Inch / 5 Quart Deep Camp Dutch Oven, 4.125 inch depth							
<i>item</i>	14 LB	11.75 L	10.5 W	6 H	0.43 FT ³	075536-38110-7	
<i>case</i>	14 LB	11.63 L	11.38 W	7.75 H	0.57 FT ³	1-00-75536-38110-4	1 PACK



L12C03 12 Inch / 6 Quart Camp Dutch Oven, 3.75 inch depth							
<i>item</i>	20 LB	14 L	12.13 W	7.75 H	0.76 FT ³	075536-38120-6	
<i>case</i>	20 LB	13.38 L	13.25 W	7.38 H	0.72 FT ³	1-00-75536-38120-3	1 PACK



L12DC03 12 Inch / 8 Quart Deep Camp Dutch Oven, 5 inch depth							
<i>item</i>	21 LB	14 L	12.13 W	8.75 H	0.86 FT ³	075536-38125-1	
<i>case</i>	21 LB	13.5 L	13.38 W	8.75 H	0.85 FT ³	1-00-75536-38125-8	1 PACK



LODGE CAMP OVENS INCLUDE*

Camp Dutch Oven Cooking 101

Our 64-page illustrated guide is filled with easy recipes and practical tips for the avid or aspiring outdoorsman.

***NOT INCLUDED IN L6C03**