

Scotch-Brite™ Scotchbrick™ Griddle Scrubber 9537 and 9537CC

Technical Data

September 2011

Description:

The Scotch-Brite™ Scotchbrick™ Griddle Scrubber 9537 and 9537CC is an easy-to-use, one piece griddle scrubber. It has a built-in heat resistant handle, bonded to an aggressive scouring pad made from synthetic fibers, minerals, and resin. It is designed to be used for cleaning flat top griddles.

Special Features:

- Tough, non-rusting and resilient high quality synthetic fibers to provide long lasting usage.
- Abrasive minerals selected to provide superior scouring for griddle cleaning.
- Abrasive mineral particles evenly distributed throughout the pad to ensure effective, consistent, and long lasting performance throughout the life of the pad.
- High quality bonding resin system designed to provide resistance to degradation from exposure to hot water, detergents and normal cleaning liquids.
- A combination of pad and handle to function as a tool to help keep hands away from hot and dirty surfaces.
- Aggressive, heavy duty and open pad construction to provide fast cleaning and multiple uses, resist clogging, and rinse clean easily.
- Heat resistant pad and handle to allow for cleaning griddle at operating temperature throughout the day.
- Durable handle to resist breakage and provide multiple uses.

Applications:

Use for cleaning and scouring griddles, replacement for grill bricks and/or other heavy duty scouring where a handled product is desired.

Packaging:

9537
12 Scrubbers/Case

9537CC
4 Scrubbers/Pack, 3 Packs/Case

General Use Directions:

The 9537 and 9537CC scrubbers can be used wet or dry on griddles at operating temperature up to 450°F.

1. Hold scrubber by the handle with one hand.
2. Place the pad side against griddle surface, apply pressure evenly and scrub griddle surface in circular motion.
3. Clean scrubber after each use.

Scrubber Cleaning Instructions:

Cleaning scrubber provides multiple uses. Used and/or worn-out scrubber can be disposed of in regular kitchen trash.

Scrubbers can be rinsed with warm hot water or soaked in a cleaning solution to dissolve caked-on soil and grease.

Scrubber Cleaning by Hand

1. Spray or rinse excess food debris from scrubber using a dish sprayer or sink faucet.

2. Wash the scrubber in soapy water to remove any remaining food debris and grease. Remove imbedded food debris from the pad by hand.
3. Rinse the scrubber with clean water. Make sure no food debris is left on the pad. Shake excess water from scrubber and allow to air dry.

Scrubber Cleaning by Dishwasher

1. Spray or rinse excess food debris from scrubber using a dish sprayer or sink faucet.
2. Place the scrubber in dishwasher and make sure the pad side is exposed to washing.
3. After washing, take scrubber out of dishwasher and allow to air dry.

Product Specifications: (Typical Values)

1. Size:
Pad length: 6.0 inches
Pad width: 4.0 inches
Pad thickness: 0.75 inch
2. Color:
Pad: Brown
Handle: Red

Precautionary Summary:

- Not recommended for use on polished or easily scratched surfaces. (Test on an inconspicuous area prior to use.)



3M Branch Sales Offices

ANCHORAGE

11151 Calaska Circle
Anchorage, AK 99515
Telephone: 907/522-5200
Facsimile: 907/522-1645

HONOLULU

4443 Malaai Street
Honolulu, HI 96818
Mail to: P.O. Box 30048
Honolulu, HI 96820
Telephone: 808/422-2721
Facsimile: 808/422-9557

CONTINENTAL UNITED STATES

Customer Service Department
3M Center Building 223-2N-20
St. Paul, MN 55144-1000
Order Entry: 800/698-4595
Facsimile: 877/318-0220

CANADA

1840 Oxford Street East
London, Ontario, Canada
N5V 3G2
Mail to: P.O. Box 5757
London, Ontario, Canada
N6A 4T1
Telephone: 800/364-3577
Facsimile: 800/479-4453

Important Notice to User:

Technical Information: The technical information, recommendations and other statements contained in this document are based upon tests or experience that 3M believes are reliable, but the accuracy or completeness of such information is not guaranteed.

Product Use: Many factors beyond 3M's control and uniquely within user's knowledge and control can affect the use and performance of a 3M product in a particular application. Given the variety of factors that can affect the use and performance of a 3M product, user is solely responsible for evaluating the 3M product and determining whether it is fit for a particular purpose and suitable for user's method of application.

Warranty and Limited Remedy: 3M warrants that each 3M product will be free from defects in material and manufacture for 90 days from the date of purchase from 3M's authorized distributor. 3M MAKES NO OTHER EXPRESS OR IMPLIED WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. If a 3M product does not conform to this warranty, the sole and exclusive remedy is, at 3M's option, replacement of the 3M product or refund of the purchase price.

Limitation of Liability: Except where prohibited by law, 3M will not be liable for any loss or damage arising from the 3M product, whether direct, indirect, special, incidental or consequential, regardless of the legal theory asserted.



Building and Commercial Services Division

St. Paul, MN 55144-1000
www.3M.com/foodservice

3M, Scotch-Brite and Scotchbrick are trademarks of 3M Company.
©3M 2011. All rights reserved
DMR 758474